

Correspondance réglage dureté de l'eau

Pour accéder au réglage: Allumer l'appareil, **maintenir Départ/Pause enfoncé pendant 5s.**

Pour modifier le réglage: Appuyer sur Départ / Pause.

REGLAGE	VOYANTS	DURETE DE L'EAU			
		°dH	°fH	°Clark	mmol/l
H1		0 - 5	0 - 9	0 - 6	0 - 0,94
H2		06 - 11	10 - 20	7 - 14	1,0 - 2,0
H3		12 - 17	21 - 30	15 - 21	2,1 - 3,0
H4		18 - 22	31 - 40	22 - 28	3,1 - 4,0
H5		23 - 34	41 - 60	29 - 42	4,1 - 6,0
H6		35 - 55	61 - 98	43 - 69	6,0 - 9,8