













DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.




DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.



DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.



DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.



DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.






Diagram Code	Diagram Description
X01	Grill Front Switch
X02	Grill Energy Regulator
X03	Left Hand Grill Element
X04	Right Hand Grill Element
X05	Left Hand Oven Thermostat
X06	Left Hand Oven Multifunction Switch
X07	Left Hand Oven Thermostat Front Switch
X08	Left Hand Oven Base Element
X09	Left Hand Oven Fan Element
X10	Left Hand Oven Top Outer Element
X11	Left Hand Oven Top Inner Element
X12	Right Hand Oven Thermostat
X13	Right oven Fan
X14	Right Hand Oven Front Switch
X15	Right Hand Oven Fan Element
X16	Oven Fan
X17	Clock / Timer
X24	Cooling Fan
X25	Cooling Fan Cut In
X26	Neon
X27	Thermal Cut Out
X28	Ignition Switches
X29	Cooling Fan Relay
X30	Spark Generator
X31	Oven Light
X32	Oven Light Switch
X36	Grill Door Cut-off Switch
X42	Terminal Connection

Code	Colour
b	Blue
br	Brown
bk	Black
or	Orange
r	Red
v	Violet
w	White
y	Yellow
gr	Grey


DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY, AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.




DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.




DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.



DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.



DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.



DISCLAIMER : THE IMAGES SHOWN ARE FOR ILLUSTRATION PURPOSES ONLY,
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.

MISCELLANEOUS 100CM T1

8010	WOK 3 UNI CONV KIT NG TO LPG
8011	WOK 3 CONVERSION INSTRUCTION
8022	IPK-GB-IE
8059	OVEN SHELF MAIN OVEN (LH)
8061	TALL OVEN 100 STANDARD SHELF
8063	TRIVET-GRILL-PAN-T1234
8070	TRAY-GRILL
8111	ASSY-OVEN-LADDERS-KIT-T12-55
8121	ASSY-OVEN-LADDERS-KIT-T1234-90/100-A
8122	ASSY-GRILL-LADDERS-KIT
8137	SET-SPANEL
8139	MAGNET FERRITE 60x20x15
8140	BASE LIFTING EQUIPMENT [SPANNER-DR-HDL]
8141	CVR-REAR-100
8144	ASSY-PLINTH-100
8164	BADGE-KITCHENER