

Liste codes erreurs









✠

		4.0	1/	9 13 50	1 3 40 01							
4	Valeurs sonde température											
Ĭ	T(°C)	R(kΩ)	T(°C)	R(kΩ)	T(°C)	R(kΩ)	T(°C)	R(kΩ)				
	-30	34.387	-18	17.052	2	5.875	8	4.370				
	-28	30.490	-16	15.242	3	5.588	10	3.969				
	-26	27.072	-10	10.968	4	5.317	15	3.135				
	-24	24.069	-5	8.410	5	5.060	20	2.494				
ĺ	-22	21.429	0	6.499	6	4.817	25	1.997				
Î	-20	19.103	1	6.178	7	4.587	30	1.610				

La solution assistance



Câblage platine





	1	ACL	Phase		1	GND		GND	
CN1	2	-	1-		2	GND	F	GND	
CIVI	3	-	-		3	RLD		Sonde dégivrage	
	4	ACN	Neutre	CN3	4	LC		Sonde réfrigérateur	
	1	ACN	Neutre		5	LD		Sonde congélateur	
	2	ACN	Neutre		6	RV	0	-	
CN2	3	-	10 it in		7	RP	2 1	tourn	
CNZ	4	COMP	Compresseur	CN7	1	RX	10	MITCE	
	5	-	-		2	TX		Afficheur	
	6	HEAT	Résistance dégivrage		3	GND		Ameneui	
	1	+12V	Éclairage réfrigérateur		4	+5V			
	2	RLed	Ecialiage reinigerateur	CN5	1	FB			
CN4	3	FLed	Églairaga congélatour		2	FAN		Ventilateur	
CIV4	4	+5V	Éclairage congélateur		3	GND	Ja.		
	5	RDoor	Interrupteur porte réfrigérateur						
	6	FDoor	Door Interrupteur porte congélateur						

La solution assistance